

## **VW GOLF MK1 G60 CONVERSION CONTENTS LIST**

1. INTERCOOLER
2. RADIATOR
3. FITTED SPAL FAN
4. ALLOY PIPEWORK WITH FITTED SENSOR BOSS AS ORIGANOL FITMENT
5. ALLOY 90 DEGREE 63MM OD PIPE
6. ALLOY 70MM OD STRAIGHT CONNECTING PIPE
7. 90 DEGREE 70MM OD ALLOY PIPE
8. 5 PIECES SILICON
9. 4 M6 BOLTS AND WASHERS
10. 4 X M6 BOLTS, NUTS AND WASHERS
11. 5 PIECE SILICON SET FOR WATER HOSES
12. 2 ALLOY JOINERS FOR WATER SIDE
13. FAN SENDER SWITCH

## **VW GOLF MK1 G60 FITTING INSTRUCTION GUIDE**

1. REMOVE RADIATOR AND FAN ASSEMBLY FROM FRONT OF CAR WHERE APPLICABLE.
2. FIT INTERCOOLER IN TO FRONT OF CAR AND DRILL AND BOLT BRACKETS WHERE THEY LINE UP WITH CAR BODY.
3. BOLT RADIATOR TO INTERCOOLER USING M6 BOLTS PROVIDED
4. FIT FAN ON RADIATOR BRACKETS USING M6 NUTS & BOLTS PROVIDED
5. FIT 90 DEGREE SILICON REDUCER (60-63MM) TO PLENUM
6. FIT 220MM LONG ALLOY PIPE WITH BAYONET SENSOR BOSS FITTEN IN TO SILICON REDUCER AND FIT IN SENSOR
7. FIT 90 DEGREE 63MM SILICON ELBOW TO THIS PIPE
8. FIT 90 DEGREE ALLOY ELBOW IN TO SILICON
9. FIT SILICON STRAIGHT JOINER 125MM LONG TO INTERCOOLER BOTTOM PIPE.
10. FROM SUPERCHARGER FIT STRAIGHT REDUCER SILICON (76-70MM)
11. THEN FIT STRAIGHT ALLOY CONNECTOR 80MM LONG 70MM OD
12. THEN FIT SILICON STRAIGHT CONNECTOR 180MM LONG
13. THEN FIT 90 DEGREE ALLOY ELBOW 70MM OD
14. THEN FIT STRAIGHT SILICON CONNECTOR 130MM LONG BACK TO INTERCOOLER. INTERCOOLER SIDE SHOULD NOW BE FULLY PIPED IN
15. FIT 90 DEGREE 32OD SILICON PIPE TO ENGINE
16. FIT ALLOY SHAPED CONNECTOR IN TO PIPE
17. FIT 90 DEGREE SILICON ELBOW BACK TO TOP PIPE OF RADIATOR
18. FIT 90 DEGREE 32 OD SILICON PIPE TO ENGINE
19. FIT 70MM LONG ALLOY JOINER TO PIPE
20. FIT 90 DEGREE SILICON ELBOW BACK TO RADIATOR BOTTOM PIPE

21. FIT SUPPLIED 8MM ID SILICON HOSE BACK TO HEADER TANK  
WHERE APPLICABLE

22. FIT FAN SENDER SWITCH IN TO RADIATOR AND WIRE IN.

IF YOU FEEL ANY DETAIL IS MISSING FROM THIS LIST THAT SHOULD HAVE  
BEEN ADDED IN PLEASE CALL 01543-502525 ANY ADVICE GIVEN IS  
GREATLY APPRECIATED.